

Fabric Mouse Pad

Fabric and Supplies	
1	Piece of Fabric large enough to cover the mouse pad about 10" x 10"
1	Piece of Fusible Interfacing large enough to cover the mouse pad about 10" x 10"
1	Mouse pad - Must be the rubber style mouse pads. The plastic or plastic coated ones will not work.



1. Cut the fabric roughly 1" bigger than your mouse pad. Fussy cut the design if needed.
2. Cut the fusible interfacing slightly smaller than the fabric.
3. Iron the fusible interfacing to the wrong side of the fabric.
 - a. Follow manufacturer's instructions.
4. Remove the paper backing.
5. Position the mouse pad on the fabric
6. Iron the fabric to the mouse pad
 - a. Yes, the rubber may smell a little, but that will go away
7. Trim the fabric to fit the mouse pad.
 - a. If you have a 'square cornered' mouse pad, round the corners. This will help prevent the fabric from peeling up over time.

